

NUVITE offers a full line of quality products, systems and equipment for Brightwork, Paint Care, Exterior Wash & Interior Care. All NUVITE products have been engineered to meet the most demanding polishing requirements. Count on NUVITE for:

- ✓ TOP PERFORMANCE
- ✓ EXTRAORDINARY RESULTS
- ✓ EXCEPTIONAL PROTECTION
- ✓ LONGER LASTING SHINE
- ✓ ECO-FRIENDLY
- ✓ USER-FRIENDLY
- ✓ COST-EFFECTIVE

NUVITE Chemical Compounds is a global leader in appearance maintenance chemicals, manufacturing and delivering high quality products for 70 years to aviation/aerospace, automotive, marine, rail, RV & power sports. The NUVITE product line delivers everything you need to achieve that most coveted, sought after, "SHOWROOM SHINE!"

NUVITE is a division of UNIVERSAL PHOTONICS INCORPORATED, manufacturer and global distributor of critical surfacing and polishing materials. UPI's dedication to innovative polishing materials supports NUVITE with state-of-the-art manufacturing facilities and an unwavering commitment to product development.

NUVITE customers can expect fast, dependable service and accurate technical assistance. Questions? Contact a NUVITE Field Technical Specialist.



[WWW.NUVITECHEMICAL.COM](http://WWW.NUVITECHEMICAL.COM)

**HOW  
TO**



**SHINE**

**AEROSPACE / TRANSPORTATION  
APPEARANCE MAINTENANCE CHEMICALS**



**BLEND SUPPLY**

DISTRIBUTOR OF COATINGS, TOOLS & REFINISH SUPPLIES

817-529-7710 | [orders@blendsupply.com](mailto:orders@blendsupply.com)

**Nuvite**  
CHEMICAL COMPOUNDS  
800.394.8351 • 516.935.4000



A DIVISION OF UNIVERSAL PHOTONICS INCORPORATED  
[WWW.UNIVERSALPHOTONICS.COM](http://WWW.UNIVERSALPHOTONICS.COM)

H2S/1018

BRIGHTWORK  
PAINT CARE  
INTERIOR CARE

[WWW.NUVITECHEMICAL.COM](http://WWW.NUVITECHEMICAL.COM)

## METAL CARE



**STEP 1:** Apply sparingly with wool compounding pad on circular buffer (1600-2000 rpm).

**STEP 2:** Polish until oxidation & residue disappear, about 60 seconds.

**STEP 3:** Repeat if oxidation cloudiness remains.

**STEP 4:** If swirl marks remain, follow with NUSHINE IIC.

**STEP 5:** Final finish with NUSHINE IIS with random orbital buffer & cotton.



**STEP 1:** Apply sparingly with tufted wool compounding pad on circular buffer (1600-2000 rpm).

**STEP 2:** Polish until oxidation & residue disappear, about 60 seconds.

**STEP 3:** Final finish with NUSHINE IIS with random orbital buffer & cotton.



**STEP 1:** Apply sparingly with cotton flannel rag by hand or with orbital-type power polisher (pad faces covered with cotton flannel sheet).

**STEP 2:** Polish until residue disappears, about 60 seconds.



NUVITE specializes in complete polishing systems. Tell us about your application & we'll put together a set of qualified consumables or have our R&D team develop a customized polishing system unique to your specifications.

# nuimage

### Polish Touch-up

**STEP 1:** Apply "AS IS" (do not dilute) to surface with a clean cotton flannel polishing cloth.

**STEP 2:** Spread material over target polish area, rub until product is removed, leaving a slight haze on the surface.

**STEP 3:** When haze dries polish away with a clean cotton flannel polishing cloth.

### Debugging/Residue Spot Remover

**STEP 1:** Apply "AS IS" (do not dilute) to effected area.

**STEP 2:** Spread around effected area & allow to soak.

**STEP 3:** Remove with gentle rubbing, until spot disappears.

## INTERIOR CARE



### CARPET CLEANER & SPOT REMOVER

#### Spot Cleaning

**STEP 1:** Dilute 1:16 with water. Saturate small area of clean towel and wet spot.

**STEP 2:** Use dry, clean cloth to soak/blot-out soil. Repeat if necessary.

#### Hand Cleaning

Clean with up/down, side-to-side action with dry cloth.

#### Machine Cleaning

Use with rotary type, not for use with steam or extraction machine.



#### Spot Cleaning

**STEP 1:** Dilute 1:8 with water in spray bottle. Spray surface, clean with terry towel.

**STEP 2:** Repeat as necessary.

#### Broad Area Cleaning:

**STEP 1:** Clean with up/down, side to side action.

**STEP 2:** Wipe dry with clean terry towel.



**STEP 1:** Pour small amount onto smooth cotton cloth.

**STEP 2:** Apply uniformly over surface area.

**STEP 3:** Use dry, clean cotton towel to polish to soft luster.



### Debugging by Hand

**STEP 1:** Dilute 1:12 with water. Using trigger spray to wet area.

**STEP 2:** Wipe with dampened terry towel. Buff to shine with dry towel. No need to rinse.

#### Wetwash

**STEP 1:** Dilute 1:10 with water.

**STEP 2:** Use in pressure system or apply with brush. Rinse.

#### Degreasing

**STEP 1:** Apply full strength or dilute 1:4 with water.

**STEP 2:** Allow to soak. Do not allow to dry. Use high pressure spray to blast away loosened grease. Repeat if necessary.

## PAINT CARE GLOSS, POLISH & DRYWASH



\*Product dilution determined by extent, condition & soil type.

### Wetwash

**STEP 1:** Dilute 1:8-1:20 with water. Apply with spray, mop, or cloth.

**STEP 2:** Agitate to loosen soils.

**STEP 3:** Rinse with water.

### Drywash

**STEP 1:** Dilute 1:8-1:12 with water. Apply with spray or mop/pad.

**STEP 2:** Agitate to loosen soils.

**STEP 3:** Wipe with damp, clean towel, frequently turning until surface is dry.

### Hand Wash/Wax

**STEP 1:** Use full strength or up to 1:4 dilution. Apply with spray or mop/pad.

**STEP 2:** Agitate to loosen soils. Do not allow to dry.

**STEP 3:** Hand buff dry.



**STEP 1:** Apply "AS IS" (do not dilute) with towel.

**STEP 2:** Agitate, spreading to very thin layer. Allow to dry.

**STEP 3:** Hand buff to slick, high shine.



**STEP 1:** Apply with terry towel or mophead "AS IS" (do not dilute).

**STEP 2:** Agitate uniformly over surface, spreading material to very thin layer.

**STEP 3:** Allow to completely dry.

**STEP 4:** Using clean towel or mophead, hand buff to slick, high gloss.



**STEP 1:** Pour small amount "AS IS" (do not dilute) onto terry towel.

**STEP 2:** Apply thinly & uniformly over surface.

**STEP 3:** Allow to cure until dry.

**STEP 4:** Hand buff with cotton flannel detailing cloth for extreme gloss.